
KWE MODEL 92FS

PAT.P HIGH GRADE TYPE 1/1 SCALE MODEL AIR SOFT PISTOL

OPERATION MANUAL FOR



NO.KA-13 SERIES



Head Factory: No. 22, Lane 308 Sec 3 Tung

Men Rd. E Zone Tainan, Taiwan, R.O.C.

Tel: 886-6-2691815-7 Fax: 886-6-2698364

E-MAIL: kwc@ms8.hinet.net **HOME PAGE: www.kwc.com.tw**


OPERATION MANUAL FOR MODEL 92FS SERIES

1. SAFETY DEVICE

THIS GUN HAS THE SAME SAFETY STRUCTURE AS THE REAL GUN.

shooting

no shooting



- Push the safety lever forward to "F" to release the gun from safety lock.
- NOTICE: pull the safety lever backwarduntil you hear a "clock" when you donot want to shoot.


 Pull the safety lever backward to "S" for safety lock

2.LOADING BULLET

Press the magazine catch and pull out the magazine from the gun.



Do not use other BULLETS than the peculiar ones.




2) Pull the magazine lever down to load bullet.

③ Load bb bullets. (you must not load more than 12 bullets in the magazine.)

CAUTION:

To improve the hitting rate we use precision aluminium material for the barrel pipe, therefore, the use


of bullets other than those designed for this pistol may cause accident or malfunction for which we will not accept responsibility.




3.SHOOTING

 Push up the safety lever to release the gun from safety lock





 Ensure that the slide returns to its original position. (the pistol will be damaged if you pull the trigger before the slide has returned.)



Caution:

When you finish shooting, please do as follows:

- 1. Pull the magazine out point the gun in a safe direction and pull the trigger 2 or 3 times to ensure that no bullets are left in the gun.
- 2. Store the gun securely out of the reach of children.

Notice:

Keeping the gun loaded and ready to shoot for long periods of time will cause the piston spring to malfunction.

WARNING

THIS PRODUCT IS SPECIALLY DEVELOPED FOR USERS MORE THAN 14 YEARS OLD. PLEASE ENSURE THAT YOU ARE SHOOTING IN A SAFE ENVIRONMENT. WE WILL NOT BE HELD RESPONSIBLE FOR ANY ACCIDENT OR MALFUNCTION CAUSED BY IMPROPER HANDLING, ILLEGAL CONVERSION, ALTERATION, OR DISASSEMBLING OF THE REVOLVER GAS HOBBY GUN. PLEASE READ THIS OPERATION MANUAL CAREFULLY BEFORE USING THE GUN.

- DO NOT POINT THE GUN AT A PERSON, EVEN IF IT IS NOT LOADED WITH A PELLET.
- 2. DO NOT PULL THE TRIGGER, EXCEPT WHEN SHOOTING
- DO NOT LOAD ANY PELLETS WHEN YOU'RE NOT GOING TO SHOOT.
- MAKE SURE THAT NO PERSON OR ANIMAL IS IN YOUR SHOOTING RANGE.
- THE GUN SHOULD ALWAYS BE KEPT OUT OF THE REACH OF CHILDREN.
- DO NOT AIM AT A FRAGILE OBJECT AND MAKE SURE NO SUCH OBJECT IS BEHIND YOUR TARGET.
- DO NOT USE OTHER PELLETS THAN THE PECULIAR ONES.
- DO NOT TRY TO DIS-ASSEMBLE THE GUN, OR INTERCHANGE OR MODIFICATE ANY OF ITS PARTS.
- DO NOT LOOK DOWN THE MUZZLE AT ANY TIME.
- YOU MUST PROTECT YOUR
 EYES WITH SAFETY GOGGLES
 DURING SHOOTING.

OPERATION MANUAL












HOP-UP CHARACTERICTIC EXPLANATORY NOTE

HOP-UP THEORY: THE BASIC THEORY OF HOP-UP IS SPIN THEORY. WHEN
THE BB BULLET IS SHOT, THERE IS A FRICTION PUT ON
THE UPPER SIDE OF BB BULLET. THE BB BULLET SPINS
UP-WARD. THE POWER OF SPIN CAN OFFSET THE
AFFECTION OF GRAVITY, WIND POWER, AIR FRICTION...
AND PUSH BB BULLET FLY TO FARTHER DISTANCE.


THE CHOICE OF BB BULLET: FOR ALL HOP-UP SERIES OF KWC

FOR ALL HOP-UP SERIES OF KWC
PRODUCT, WE CHOOSE 0.2g BB BULLET
FOR ALL OUR CUSTOMERS. BECAUSE 0.2g
BB BULLET CAN BE SHOT TO FARTHER
DISTANCE THAN OTHER KINDS OF BULLET,
AND MORE STABLE TOO. (PLEASE SEE FIG.
AS BELOW) 0.12g, 0.16g BB BULLET ARE
TOO LIGHT, AND 0.25g BB BULLET IS TOO
HEAVY.



- CAUTION: 1. LUBE OIL WILL REDUCE THE FRICTION ON THE UPPER SIDE OF BB BULLET AND REDUCE THE EFFECT OF SPIN. PLEASE DON'T PUT LUBE OIL ON BB BULLET AND BULLET PACKING.
 - 2. IN THE BEGINNING OF USING KWC HOP-UP SERIES, THE HOP-UP PHENOMENON IS NOT SO STABLE, BECAUSE THE AFFECTION OF LUBE OIL COME FROM PISTON. AFTER SHOT 100 PCS BULLETS, THE AFFECTION OF LUBE OIL IS REDUCED TO VERY LOW LEVEL, THE HOP-UP EFFECT APPEARS.





標的射擊競技用的紙

- ★ この的紙はダンボールや発泡スチロールに セロテープでとめてお使い下さい。 固いものに貼らないこと。はねかえります。
- ★ 射撃する時、前方に人がいないか、又こわれやすいものがないか注意して下さい。

| | | | | |
|-------|----|------|---|---|
| 競技実施日 | | 年 | 月 | 日 |
| 距 | 離 | | | m |
| 射撃 | 回数 | | | |
| 得 | 点 | | | 点 |